


Installing Internal Devices on the DIN PC

Contents

Installing a 2.5" SATA HDD on the DIN PC	P2
Installing a SATA DOM on the DIN PC	P7
Installing a Wi-Fi Dongle on the DIN PC	P8
Installing an SD Card on the DIN PC	P10


Installing a 2.5" SATA HDD on the DIN PC



Step 1:

Prepare the following items.

- 1. 2.5" SATA HDD
- 2. HDD Bracket
- 3. Silicon pad sticker x 1
- 4. Shockproof ring x 4
- 5. Small screw x 2
- 6. Shockproof screw x 4
- 7. SATA HDD Cable
- 8. Phillips screwdriver



Front panel

Step 2:

Unscrew the four screws on the **front panel.**

Step 3:

Remove the **front panel**.




Back panel

A cover

Step 4:

Unscrew the two screws from the **back panel** to open the **A cover**.



DIN PC after completing steps




Place the Shockproof rings (x4) and Silicon pad (x 1) on the HDD Bracket.



Step 5: Place the 2.5" SATA HDD on the Shockproof rings of the HDD


bracket.

Note: The HDD connector needs to be on the same side of the bracket as the two holes.



Step 6:

Flip the HDD and HDD bracket over. Tighten shockproof screws (x 4) onto the shockproof rings to affix the 2.5" HDD.




Step 7:

To place the HDD bracket on the **A cover**. Insert the HDD bracket onto the track of the **A cover**, (as shown in the picture).

Step 8:

Tighten small screws (x2) into the left of the HDD bracket.





Step 9:

Connect the SATA HDD Cable and HDD power cable to the main board.


Note:

Pay attention to the direction of the HDD power cable.






Installing a SATA DOM on the DIN PC



Step 1:

Plug the SATA DOM into the SATA connector on the main board.

Plug the SATA DOM power cable to the power connector.



Step 2:

Put the **front panel** and **A cover** back on the unit.

Front panel A cover



Step 3:

Tighten the two screws on the back panel.


Installing a Wi-Fi Dongle on the DIN PC



Step 1:

Prepare the following items.

- 1. Wi-Fi Antenna
- 2. USB Wi-Fi Dongle
- 3. Wi-Fi cable 150mm
- 4. Screw nuts




Step 2:


Attach the Wi-Fi cable onto the connector on the rear side of the DIN PC (as shown in the picture).



Step 3:


Connect the Wi-Fi 150mm cable onto the Wi-Fi Dongle.







Insert the SD Card into the SD card slot.



Step 2:
Put the **front panel** and **A cover** back on the unit.

Front panel

A cover



Step 3: Tighten the two screws on the back panel.